

# Operating Manual

## BROSA Type 0210 Shear Force Transducer

*Version: 05/2020*

© 2018 BROSA AG, Tettngang, Germany

---

**BROSA AG**  
Dr. Klein Straße 1  
D-88069 Tettngang  
Phone: +49(0)7542 93 35 0  
Fax: +49(0)7542 93 35 35  
info@brosa.net  
www.brosa.net

**BROSA Pte Ltd**  
25 Lorong Kilat #02-01  
Singapore 598126  
Phone: +65 6795 2324  
Fax: +65 6795 2428  
info.sg@brosa.net

**BROSA B.V.**  
Galliershof 38  
NL - 5349 BV Oss, Netherlands  
Phone: +31 412 6146 02  
Fax: +31 412 6146 86  
info@brosa.nl

**BROSA (Nanjing) Co., Ltd.**  
Jinma Lu 3, Maqun Scientific Park, Qixia District  
210049 Nanjing  
Phone: +86 (25)8222 4639  
Fax: +86 (25)8222 4639  
info.cn@brosa.net

---

## Notes

---

## Contents

|       |   |    |
|-------|---|----|
| 1     | General information .....   | 4  |
| 1.1   | Safety instructions – Explanation of symbols:.....                          | 4  |
| 2     | Description of the BROSA shear force transducer.....                        | 5  |
| 2.1   | Structure and functionality .....   | 5  |
| 2.2   | Information on explosion protection .....                                   | 7  |
| 2.3   | Label (nameplate, indication of measuring direction) .....                  | 7  |
| 3     | Advice on the safe handling of BROSA shear force transducers.....           | 9  |
| 3.1   | Handling .....  | 9  |
| 3.2   | Installation and commissioning .....  | 10 |
| 3.2.1 | General information .....   | 10 |
| 3.2.2 | Additional information for operation in areas subject to explosion hazards. | 11 |
| 3.3   | Operation and maintenance .....   | 13 |
| 3.3.1 | Operation .....   | 13 |
| 3.3.2 | Maintenance .....   | 14 |
| 3.4   | Disassembly .....   | 14 |
| 3.5   | Disposal .....  | 15 |

## 1 General information

Read the operating instructions and the product-specific documents carefully before commissioning the sensor.

Make sure that the sensor is fully suitable for the applications in question.

Improper use or any use other than intended may result in a malfunction of the sensor or undesirable effects in your application. For this reason, installation, electrical connection, commissioning and maintenance of the sensor may only be carried out by trained personnel authorized by the plant operator.

We also expressly point out that any liability is excluded if instructions in this documentation are disregarded.

Only the German version of this operating manual represents the original document.

### 1.1 Safety instructions – Explanation of symbols:



**WARNING!** This symbol indicates dangers that can lead to personal injury and property damage!

---

## 2 Description of the BROSA shear force transducer

### 2.1 Structure and functionality

The BROSA type 0210 shear force transducer is used to measure the force in single-shear connections in or on machines and equipment of all kinds. Figure 1 shows the typical layout:




Figure 1: Shear force transducer

The shear force transducer consists of a cylindrical or cuboid measuring body(1), which holds the load to be measured and has features for securing it torsionally and axially (1a), as well as a connection support (2), which is permanently connected to the measuring body and on which - if not placed directly on the measuring body - the necessary elements for the electrical connection (connector or cable) are attached and which - if not placed in the measuring body - contains the measuring electronics. The constriction (1b) in the measuring body for technical measurement reasons can be provided with a filling depending on the application or optionally on request. Optionally, the measuring body can contain elements to lubricate the bearing (1c). The measuring body and, if applicable, the connection support are made of stainless steel.

The use below the water surface is generally possible after testing and approval by BROSA, special requirements are the used materials, the tightness and the electrical connections. In addition, there is the possibility that the water pressure impacts the measurement result.

Figure 2 shows the typical installation conditions:




Figure 2: Installation conditions

The shear force transducer (1) is connected to the surrounding structure (2) directly or by fasteners. Force  $F$  transmitted by the connection is transmitted to the measuring electronics through analysis of the resulting deformation of the measuring body and output as an electric signal.

Versions with two measuring systems and/or measuring directions, either with output signals on separate connectors/cables or combined in one connector/cable, are optionally available. More information can be found in the technical data sheets, which may be obtained free of charge from BROSA.

## 2.2 Information on explosion protection

The type 0210 shear force transducer can be optionally obtained in an intrinsically safe design for use in environments with explosion hazards. This can be done with the 2-wire technique using the ExDANGmicro2W\*\*\* amplifier. The following specifications apply:

|  |   |
|--|---|
|  | Amplifier<br>ExDANGmicro2W***   |
| Ignition protection type:  | Ex II2G Ex ib IIC T4 Gb<br>Ex ib IIC T4 Gb  |
| Certificate number:  | BVS 16 ATEX E 041<br>IECEX BVS 16.0031  |
| Safety-related limit values:   |   |
| <ul style="list-style-type: none"> <li>• Maximum voltage <math>U_i</math></li> <li>• Maximum current <math>I_i</math></li> <li>• Indoor capacity <math>C_i</math></li> <li>• Internal inductance <math>L_i</math></li> </ul> | <ul style="list-style-type: none"> <li>= 30V DC</li> <li>= 100 mA</li> <li>= 24 nF + 0.3 nF/m</li> <li>= 3 <math>\mu</math>H + 1 <math>\mu</math>H/m</li> </ul> |



Use of intrinsically safe shear force transducers in zone 0 is not allowed.

## 2.3 Label (nameplate, indication of measuring direction)

Each BROSA shear force transducer is equipped with an indicator plate(1) containing the respective information applicable for the given product. It is attached to one of the outer surfaces of the measuring body or the connection support (see figure 3).




Figure 3: Nameplate positions, measuring direction


The measuring direction is indicated on the front side with an arrow (Figure 3, 2).


In the optionally available version with two measuring directions, the measuring directions are labelled as shown in Figure 4:




Figure 4: Measuring direction X-Y-SKA

### 3 Advice on the safe handling of BROSA shear force transducers

 **WARNING!** Non-compliance with the following instructions can lead to sensor damage and/or impairment of measurement results. The analysis of an erroneous measurement can result in personal injury or material damage.

 **WARNING!** Despite their sturdy design, BROSA shear force transducers may not be used for any other than the intended purpose (see. Section 2.1). Improper use can result in dangers to the life and limb of the user or third parties and/or impairment of the device in which the shear force transducer is implemented or other property.

#### 3.1 Handling

 **WARNING!** BROSA sensors contain high-quality measurement electronics. Make sure they are handled carefully.

- BROSA shear force transducers are delivered in transport-safe packaging. We recommended that you remove the sensors from the package immediately prior to installation.
- The mass of the shear force transducer should be taken into account for the selection of handling and/or lifting devices; it is indicated on the nameplate.
- BROSA shear force transducers must be secured against falling. Do not throw sensors!
- Use as a tool (e.g. striking, slotting or lever tool) is not permitted; it can cause damage to the sensor and thus falsify the measurement results.

## 3.2 Installation and commissioning

### 3.2.1 General information

We recommended taking the following actions in the given order using the “four-eye principle”.

- a) Inspecting the sensor - measuring point assignment: It must be ensured that the sensor to be installed is designed for use at the intended measuring point. For this purpose, check information on the nameplate, in particular the item or the identification number and the measuring range, against the data of the measuring point.



**WARNING!** A sensor not designed for the particular measuring point must not be installed.

- b) Inspection of the sensor for intactness and function: It must be ensured that the sensor to be incorporated is free of damage of any kind.



**WARNING!** A damaged sensor must not be installed!

- c) Installation of the sensor at the measurement position: The shear force transducer should be connected to the surrounding structure directly or with the help of the intended fasteners.



**WARNING!** The shear force transducer must not be aligned using impact tools!

---

After alignment, the shear force transducer must be secured against movement and twisting with the appropriate elements. Attention must be paid to the correct alignment of the shear force transducer to the intended measuring direction (see front mark, compare Section 2.2.)



**WARNING!** A misaligned sensor leads to erroneous measurement results!

- d) Establishment of electrical connection: The elements on the sensor for the electrical connection are to be connected to the power supply, the earth connection if necessary, and the evaluation system of the device. In doing so, the information given on the nameplate for connector or cable assignment and, if applicable, the installation guidelines of the cable are to be observed.



**WARNING!** An incorrect or incomplete electrical connection impairs or prevents measurement.

- e) Functional check: After completed mechanical (see c) and electric (see d) installation, load on the sensor is to be applied over the entire measuring range; the output measurement signals are to be subjected to a plausibility check.



**WARNING!** If due to unusual events (e.g. deformation or unusual noise), measurement results are considered implausible or there is suspicion that the sensor is malfunctioning for any other reason, it must not be put into operation.

### 3.2.2 Additional information for operation in areas subject to explosion hazards



Only those sensors with the corresponding labels are approved for use in areas subject to explosion hazards.

If the open cable end is connected inside an area subject to explosion hazards, the connection must be inside a terminal box/switching cabinet certified in accordance with the ATEX-directive. If it is connected outside an area subject to explosion hazards, it must be in line with the general requirements for electrical equipment.

#### 3.2.2.1 Type 0210 in an intrinsically safe version

The sensors with ExDANGmicro2W\*\*\* amplifier must be installed according to the following specifications:




Figure 6: Connection example of sensor Ex i with Ex DANGmicro2W\*\*\* amplifier

The supply and the measurement signal are guided over isolation amplifiers in the areas subject to explosion hazards. Isolation amplifiers from other manufacturers can also be used if they meet the safety-related limit values.

During the installation, the differentiation of the insulation resistance of the strain gauge resistance bridge versus the spring body sensor must be taken into account. The amplifier type ExDANGmicro2W\_A\*\* is to be regarded as separate from the spring body. The amplifier type ExDANGmicro2W\_B\*\* is to be regarded as connected to the spring body in case of error.

The laying of the connection cable with the amplifier type ExDANGmicro2W\_\* B2 and type ExDANGmicro2W\_\* B4 requires protection against damage and tensile load, guaranteed by proper installation.

The complete list of possible amplifier configurations can be found in the certificate.

---

## 3.3 Operation and maintenance

### 3.3.1 Operation

BROSA shear force transducers operate automatically; attaching tools is not required for operation. Direct manual intervention by the operator is not necessary; there are therefore no requirements for the operator to wear protective equipment during operation. However, the requirements towards the device in which the shear force transducer is installed must be observed.

BROSA shear force transducers emit neither airborne acoustic noise nor non-ionising radiation.


Operation of BROSA shear force transducers is permitted only within the parameters and properties given in the technical data sheets and on the nameplate. These are, among others:

- Measuring range
- Temperature range
- Permissible supply voltage
- Electrical protection class
- Material

It must be ensured that no parasitic influences such as forces or torques transverse to the direction of measurement are transmitted via the shear force transducer.

Inductive or capacitive coupling with the connection cable(s) of the sensor can distort the measurement result and must be avoided. Some examples of these kinds of couplings can be caused e.g. by unfavourable cable routing (parallel power lines, frequency converters, transformers, motors, incorrect grounding/shielding and the like).

When performing electric welding in the vicinity of the sensor, all connections must be disconnected and isolated. It must be ensured that no welding current is flowing through the sensor.

 **WARNING!** Operation outside the specified parameters or contrary to existing properties or improper use can damage the sensor and cause it to fail or lead to faulty measuring results. If the sensor is overloaded, this can lead to the whole machine being equally overloaded and possibly endangering its stability.


### 3.3.2 Maintenance

In its capacity as a sensor, BROSA shear force transducers are maintenance-free. As load-transmitting elements, however, they are subject to mechanical stress, requiring regular inspections of the fault-free state of each shear force transducer. The intervals between inspections depend on the intensity of use and must be determined by the end-user.

An inspection includes the following points:

- Visual inspection for damage to the measuring body and wiring as well as soiling
- Function test/plausibility check


The causes of existing errors are to be identified and remedied. If the test indicates an improper sensor state, it must be taken out of operation. If a malfunction or damage is detected on the sensor, it must be sent to the manufacturer's factory for diagnosis and, if necessary, repaired.

 **WARNING!** The sensor may only be repaired at the factory. Intervention (e.g. opening, mechanical processing and the like) done by parties other than the manufacturer means the safe operation of the sensor is no longer ensured and voids the warranty.


### 3.4 Disassembly

We recommend performing the following actions in the order given.

a) Ensuring freedom from loads at the measurement position: The shear force transducer should be unloaded before disassembly.

 **WARNING!** The disassembly of a shear force transducer under load leads to high risks to life and limb of persons in the vicinity and can cause major damage. This is therefore not permitted.

- b) Undoing the electrical connection
- c) Remove the mechanical securing elements
- d) Removal of the bearing force transducer

 **WARNING!** If the shear force transducer is to be reused, it must not be removed with the aid of impact tools!

---

### 3.5 Disposal

If the end of the service life is reached, the shear force transducer is to be taken to an environmentally-friendly disposal facility. Since the non-metallic components constitute a small part of the mass of the shear force transducer, the rod may be recycled as a whole as scrap steel. Assignment as stainless steel scrap is preferable.

If the sensor is stored before final disposal, an appropriate storage location is to be selected which prevents harmful substances from entering the environment. If necessary, the sensor must be cleaned.



**WARNING!** BROSA shear force transducers contain traces of environmentally hazardous substances. This is also true of the impurities created during use. Contamination of the environment by these substances is to be prevented.